DMX-protocol

Control channel 1 - Colour-wheel

DMX-value	Feature	DMX-value	Feature
0-17	Open/white	144-161	Light green
18-35	Red	162-179	Light blue
36-53	Yellow	180-197	Orange/yellow
54-71	Violet	198-215	Light yellow
72-89	Green	216-233	Magenta
90-107	Orange	234-251	Color mixing (red with blue)
108-125	Blue	252-255	Color mixing (yellow with green)
126-143	Pink		

Control channel 2 - Gobo-wheel

DMX-value	Feature	DMX-value	Feature
0-17	Open	144-161	Gobo 8
18-35	Gobo 1	162-179	Gobo 9
36-53	Gobo 2	180-197	Gobo 10
54-71	Gobo 3	198-215	Gobo 11
72-89	Gobo 4	216-233	Gobo 12
90-107	Gobo 5	234-251	Gobo 13
108-125	Gobo 6	252-255	Gobo 14
126-143	Gobo 7		

Control channel 3 - Shutter, strobe

DMX-value	Feature
0-14	Shutter closed
15-29	Open
30-250	Strobe-effect with increasing speed
251-255	Open